


# INSTALLATION INSTRUCTIONS

FOR TREMOLO BRIDGES 2229, 2231  
 9 & 10 STRING SERIES




**X** : LOCATION OF STUD MOUNTING HOLES (USE CENTERLINE OF FRETBOARD).  
**SCALE LENGTH MEASUREMENT FOR CORRECT INTONATION** IS FROM  
 CRITICAL CONTACT POINT (CCP) AT NUT AND TO THE CENTER OF  
 SADDLE TRAVEL (CST).

**Y** : LOCATION OF (2) STUD MOUNTING HOLES (USE CENTERLINE OF FRETBOARD)  
**ALIGNMENT LEFT & RIGHT FOR CORRECT STRING LOCATION** ON  
 FRETBOARD. (NOTE: L-R SADDLE ADJUSTMENTS ON BRIDGE).




DWG is to offer assistance to a qualified Luthier. We do not guarantee 100% satisfaction on this DWG, therefore the Luthier is 100% responsible for the measurements and routings.	KAHLER INTERNATIONAL INC.		
	TITLE: LOCATION MEASUREMENTS ASSY: 2229, 2231		
	DWG. NO. 6208RIMA		
	DRAWN: TASC	DATE: 04/18/12	SCALE: 1:1

LOCATION FOR ROUTING SHAPE AND DEPTH FOR  
**CORRECT CAM AND SPRING ACTION**



BRIDGE MOUNTING PLATE LOCATION AND  
 HEIGHT MEASUREMENT FOR **CORRECT STRING ACTION**



DWG is to offer assistance to a qualified Luthier. We do not guarantee 100% satisfaction on this DWG, therefore the Luthier is 100% responsible for the measurements and routings.	KAHLER INTERNATIONAL INC.		
	TITLE:	ROUTING/FRET HT. MEASUREMENTS ASSY: 2229, 2231	
	DWG. NO.	6208RIMA	
	DRAWN: TASC	DATE: 04/18/12	SCALE: 1:1